



# ULTRA FLOOR-TO-CEILING

INSTALLATION GUIDE: 1-Sided & 2-Sided

**RECOMMENDED TOOLS:** Tape measure, Level, Pencil, Electrical drill, Stud finder, Hammer, and Clamps

## PACKAGE CONTENTS

QTY	Description
1 set of 2	Ultra Floor-to-Ceiling Frame
40	¼" Self-tapping Screws
1 set of 2	Backer Channel*

\*Backer channel not included for 2-Sided Floor-to-Ceiling.

## INSTALLATION STEPS

**IMPORTANT:** When securing the FTC to a location, use the appropriate mounting fasteners. There are 4 fastener locations on the top and bottom brackets.

### STEP 1: MARK SCREW HOLES

Mark the screw holes for the mounting brackets in the desired mounting location.

### STEP 2: MEASURE CEILING HEIGHT

Measure the ceiling height in the location you will mount the frame.

### STEP 3: MAKE CALCULATIONS

Calculate the height of your ceiling, then subtract 60 3/16" (the height of the top frame, with connector) to give you the measurements for your bottom rail. (For example: 96" - 60 3/16" = 35 13/16")

### STEP 4: MARK BOTTOM FRAME

Mark the bottom frame to determine the cut location.

### STEP 5: CUT FRAME

Cut the frame in marked location using a metal-cutting hack saw.

**Note:** Do not use a metal cut off wheel as the heat will damage the product.

### STEP 6: MOUNT BRACKETS

Mount the brackets to the ceiling then the floor using the appropriate anchors. Do not over-tighten.


**PRO TIP:** Pre-drill holes before installing the Floor-to-Ceiling mount.

### STEP 7: MOUNT RAILS AND/OR BACKER CHANNEL


Mount rails and/or backer channel to frame. Use all mounting holes to fasten rails securely. **PRO TIP:** Use clamps to hold rails in place while mounting.

### STEP 8: INSERT END CAPS AND DOME CAPS

Add the finishing touch by inserting end caps and dome caps. Congratulations!



1-Sided Floor-to-Ceiling



2-Sided Floor-to-Ceiling

